**KINGWIN**

## 2.5" / 3.5" Internal Tray-Less Hot Swap Rack

# USER'S MANUAL
# KF-252-BK

CE FC SERIAL ATA

---

## Specifications

• Product name: KF-252-BK
• OS: Windows Vista/ XP/2000/98SE/ME: Win 7, MAC 10X+
• Interface: Supports SATAII ( 3.0 Gb/s)
• Fits all 2.5" or 3.5" SATA hard disk
• Support hot swap
• Material: Stainless Steel & ABS Plastic
• Dimensions: 110mm( 4 5/16")L x 146mm (5 3/4") W x
  41mm (1 5/8") H
• Weight: 180g (0.4LBS)
• Color: Black
• Operation Temperature:  0° - 55° C

### Front panel

1. For 2.5" SATA hard disk
2. For 3.5" SATA hard disk
3. Power/Access LED light
4. Power On/Off bottom

### Rear panel

1. 4pin Molex connector
2. SATA Power 15Pin+ SATA Data 7Pin
3. Air vent

---

## Installation

1.

1. Remove the slot cover of
an empty 3.5" floppy bay

2. Carefully insert the KF-252-BK
into the bay and push it inward
until the KF-252-BK screw hole is
aligned with the hole of the bay

2.

3.

3. Secure the KF-252-BK with the
packed screws. Use 2 screws on
each side to securely hold the device

---

## Connect the HDD–ROM cable

1.Insert the SATA Power 15P +SATA
Data 7P connecter into the KF-252-BK,
then another end connect to PC power
plug, and motherboard or the SATA
RAID card

2. OR Insert Molex 4P Power + SATA
7P cable to the KF-252-BK, then
another end connect to PC power
plug, and motherboard or the SATA
RAID card

⚠ Before connecting the patent 7+15P or 4pin Molex cable
with PC or with the KF-252-BK, please check and make
sure there are no objects beside the connectors that may
affect the mechanical assembly or become a possible
source of an electrical short

## Install HDD

1. Install 2.5'' hard disk to KF-252-BK

2. Install 3.5'' hard disk to KF-252-BK

---

⚠ 1) After inserting HDD, carefully push until it is seated into
position. Excessive force may damage its mechanical parts.
2) If the HDD is inserted backward into the tray, forcing the device
may damage the KF-252-BK

⚠ **Kingwin is not responsible for any data loss or HDD
damage in the process of using the KF-252-BK**